



Module Quality Control & Assurance

Anthony Affolder University of California, Santa Barbara

Tracker Annual Review 2003, A. Affolder, UCSB

Module Quality Control & Assurance



Outline

- Mechanical Quality Control & Assurance
 - → Gantry calibration & qualification
 - → Module quality
- Wire Bonding Qualification & Testing
 - → Qualification of pitch adaptors
 - → Wire bond pull tests
- Electrical Qualification & Testing
 - → Test stand types & part flow
 - → Test stand qualification & cross-calibration
 - → Module test & grading

Review of Production Network



General QC&A Philosophy



- How can process quality and uniformity be guaranteed in such a distributed system?
 - → 7 module assembly centers
 - → 13 module bonding and testing centers
 - \rightarrow 9 sub-detector assembly and testing centers
- Require that equipment, software, and procedures used are as identical as possible
 - Cross-calibrations are performed between sites in which standard candles (glass plates, hybrids, modules, etc.) are exchanged
- Require a high level of traceability of component/module flow and of testing results at all stages (Database)
 - → Global quality of production can be monitored
 - Quick feed-back to production center, improving process quality and uniformity



Gantry centers



- Identical gantry systems assemble modules from components
 - → Bari and Perugia => TIB/TID Modules
 - → Brussels, Lyon and Wien => TEC Modules
 - → FNAL and UCSB =>TOB Modules
- Identical software used at all seven gantry cites



TEC

TIB

TOB



Gantry Qualification

All centers have qualified gantries through measurement of standard glass plates and production of multiple dummy modules

			BAR			BF	UXEL	LES			FNA	L
	<x></x>	v	<y></y>	v	<x></x>	v	<y></y>	v	<x></x>	v	<y></y>	v
MANUAL POSITION REPETIBILITY		0.9		1.1		^		-		^		T
PR INTRINSIC REPEATIBILITY		0.05		0.06	0.016	0.18	0.03	0.07		0.08		0.05
PR GLOBAL REPEATIBILITY		1,2		1,6	1,26	1,97	-0,3	2,198		0,3		0,3
PICK AND PLACE	1,05	1,04	0,9	1,28	0,007	0,7	-0,01	0,94		1,5	i	1,6
CORRECTION FOR ROTATION	SINUS	OIDAL I	BEHAV	IOUR	NON P	ARTIC	ULAR B	EHAVIO	U SINUS	SOIDAL	BEHAV	OUR
	LARGE	ECORF	RECTIO	NS	VERY	SMALL	CORR	ECTIONS	SMAL	L CORR	RECTIO	NS
			LYON		_		PERU	GIA			UCSB	
	<x></x>	x	<y></y>	v	<x></x>	x	<y></y>	v	<x></x>	x	<y></y>	v
MANUAL POSITION REPETIBILITY		~				0.5	5 0.6	;	_	0.9	0.6	
PR INTRINSIC REPEATIBILITY		0.27		0.1		0.5	5		_	0.06		0.06
PR GLOBAL REPEATIBILITY		0.2		0.31		0.5	5		_	0.3		0.6
PICK AND PLACE		0.22		0.41		- , -	-0.3	1.4	_	1		1
CORRECTION FOR ROTATION	SINUS		BEHAVI	IOUR	SINUS	OIDAL	BEHA\	/IOUR	SINUS	SOIDAL	BEHAV	IOUR
	SMALL	CORR	ECTIO	NS	SMALL	CORF	RECTIO	NS	VERY	SMALL	CORRE	CTION
The prec	isi	.011	0	bta	ine	ed	is	wi	thi	<u>n</u> (ou :	r
	MANUAL POSITION REPETIBILITY PR INTRINSIC REPEATIBILITY PR GLOBAL REPEATIBILITY PICK AND PLACE CORRECTION FOR ROTATION MANUAL POSITION REPETIBILITY PR INTRINSIC REPEATIBILITY PR GLOBAL REPEATIBILITY PICK AND PLACE CORRECTION FOR ROTATION The prec	ANUAL POSITION REPETIBILITY PR INTRINSIC REPEATIBILITY PR GLOBAL REPEATIBILITY PICK AND PLACE CORRECTION FOR ROTATION IARGE MANUAL POSITION REPETIBILITY PR INTRINSIC REPEATIBILITY PR GLOBAL REPEATIBILITY PICK AND PLACE CORRECTION FOR ROTATION SINUS SMALL	ANUAL POSITION REPETIBILITY PR INTRINSIC REPEATIBILITY PR GLOBAL REPEATIBILITY PICK AND PLACE CORRECTION FOR ROTATION MANUAL POSITION REPETIBILITY PR INTRINSIC REPEATIBILITY PR GLOBAL REPEATIBILITY PR GLOBAL REPEATIBILITY PICK AND PLACE CORRECTION FOR ROTATION MANUAL POSITION REPETIBILITY PR GLOBAL REPEATIBILITY PICK AND PLACE CORRECTION FOR ROTATION SINUSOIDAL SMALL CORRECTION FOR ROTATION MALL CORRECTION FOR ROTATION MALL CORRECTION FOR ROTATION MALL CORRECTION FOR ROTATION	ANUAL POSITION REPETIBILITY PR INTRINSIC REPEATIBILITY PR GLOBAL REPEATIBILITY PICK AND PLACE CORRECTION FOR ROTATION CORRECTION FOR ROTATION ILYON ANUAL POSITION REPETIBILITY PR INTRINSIC REPEATIBILITY PR GLOBAL REPEATIBILITY PR GLOBAL REPEATIBILITY PR GLOBAL REPEATIBILITY PICK AND PLACE CORRECTION FOR ROTATION MANUAL POSITION REPETIBILITY PR GLOBAL REPEATIBILITY PICK AND PLACE CORRECTION FOR ROTATION SINUSOIDAL BEHAV SMALL CORRECTION SINUSOIDAL BEHAV SMALL CORRECTION SINUSOIDAL BEHAV SMALL CORRECTION CORRECTION FOR ROTATION SINUSOIDAL BEHAV SMALL CORRECTION CORRECTION FOR ROTATION SINUSOIDAL BEHAV SMALL CORRECTION CORRECTION FOR ROTATION SINUSOIDAL BEHAV SMALL CORRECTION SINUSOIDAL BEHAV SMALL CORRECTION	BARI MANUAL POSITION REPETIBILITY 0,9 1,1 PR INTRINSIC REPEATIBILITY 0,05 0,06 PR GLOBAL REPEATIBILITY 1,2 1,6 PICK AND PLACE 1,05 1,04 0,9 1,28 CORRECTION FOR ROTATION SINUSOIDAL BEHAVIOUR LARGE CORRECTIONS MANUAL POSITION REPETIBILITY 0,27 0,1 PR GLOBAL REPEATIBILITY 0,27 0,1 PR INTRINSIC REPEATIBILITY 0,22 0,31 PICK AND PLACE 0,22 0,41 CORRECTION FOR ROTATION SINUSOIDAL BEHAVIOUR SINUSOIDAL REPEATIBILITY 0,22 0,41 OCRRECTION FOR ROTATION SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SINUL CORRECTIONS	State State State Anual Position REPETIBILITY 0,9 1,1 PR INTRINSIC REPEATIBILITY 0,05 0,06 0,016 PR GLOBAL REPEATIBILITY 1,2 1,6 1,26 PICK AND PLACE 1,05 1,04 0,9 1,28 0,007 CORRECTION FOR ROTATION SINUSOIDAL BEHAVIOUR NON P LARGE CORRECTIONS VERY S ANUAL POSITION REPETIBILITY 0,27 0,1 PR GLOBAL REPEATIBILITY 0,27 0,1 PR INTRINSIC REPEATIBILITY 0,22 0,31 PICK AND PLACE 0,22 0,41 CORRECTION FOR ROTATION SINUSOIDAL BEHAVIOUR SINUS MANUAL POSITION REPETIBILITY 0,2 0,31 PR GLOBAL REPEATIBILITY 0,22 0,41 SINUSOIDAL BEHAVIOUR SINUS SMALL CORRECTION FOR ROTATION SINUSOIDAL BEHAVIOUR SINUS SMALL CORRECTIONS SMALL SMALL	BARI BARI MANUAL POSITION REPETIBILITY 0,9 1,1 PR INTRINSIC REPEATIBILITY 0,05 0,06 0,016 0,18 PR GLOBAL REPEATIBILITY 1,22 1,6 1,26 1,97 PICK AND PLACE 1,05 1,04 0,9 1,28 0,007 0,7 CORRECTION FOR ROTATION SINUSOIDAL BEHAVIOUR NON PARTIC LARGE CORRECTIONS VERY SMALL VERY SMALL VERY SMALL <td>BARI BRUXEL MANUAL POSITION REPETIBILITY 0,9 1,1 PR INTRINSIC REPEATIBILITY 0,05 0,06 0,016 0,18 0,03 PR GLOBAL REPEATIBILITY 1,05 1,04 0,9 1,28 0,007 0,7 -0,01 PICK AND PLACE 1,05 1,04 0,9 1,28 0,007 0,7 -0,01 CORRECTION FOR ROTATION SINUSOIDAL BEHAVIOUR NON PARTICULAR BEHAVIOUR NON PARTICULAR BEHAVIOUR NON PARTICULAR BEHAVIOUR MANUAL POSITION REPETIBILITY 0,27 0,1 0,5 0,6 PR GLOBAL REPEATIBILITY 0,27 0,1 0,5 0,6 PR GLOBAL REPEATIBILITY 0,27 0,1 0,5 0,6 PR GLOBAL REPEATIBILITY 0,22 0,41 -0,3 PR GLOBAL REPEATIBILITY 0,22 0,41 -0,3 PICK AND PLACE 0,22 0,41 -0,3 SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SMALL CORRECTION</td> <td>BARI BRUXELLES MANUAL POSITION REPETIBILITY PR INTRINSIC REPEATIBILITY PR GLOBAL REPEATIBILITY PICK AND PLACE CORRECTION FOR ROTATION 0,9 1,1 </td> <td>BARI BRUXELLES MANUAL POSITION REPETIBILITY 0,9 1,1 PR INTRINSIC REPEATIBILITY 0,9 1,1 PR GLOBAL REPEATIBILITY 0,05 0,06 0,016 0,18 0,03 0.07 PICK AND PLACE 1,05 1,04 0,9 1,28 0,007 0,7 -0,3 2,198 CORRECTION FOR ROTATION SINUSOIDAL BEHAVIOUR NON PARTICULAR BEHAVIOU SINUS LYON PERUGIA <x> x Y> y <x> x Y> y <x> MANUAL POSITION REPETIBILITY 0,27 0,1 0,5 0,6 0,04 PR INTRINSIC REPEATIBILITY 0,27 0,1 0,5 0,6 0,05 0,6 PR INTRINSIC REPEATIBILITY 0,22 0,41 -0,3 1,4 SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SINUS PR GLOBAL REPEATIBILITY 0,22 0,41 -0,3 1,4 SINUS PR GLOBAL REPEATIBILITY 0,22 0,41 -0,3 1,4 SINUS SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SINUS SINUS SINUSO</x></x></x></td> <td>BARI BRUXELLES MANUAL POSITION REPETIBILITY 0,9 1,1 </td> <td>BARI BRUXELLES FNA MANUAL POSITION REPETIBILITY 0,9 1,1 v</td>	BARI BRUXEL MANUAL POSITION REPETIBILITY 0,9 1,1 PR INTRINSIC REPEATIBILITY 0,05 0,06 0,016 0,18 0,03 PR GLOBAL REPEATIBILITY 1,05 1,04 0,9 1,28 0,007 0,7 -0,01 PICK AND PLACE 1,05 1,04 0,9 1,28 0,007 0,7 -0,01 CORRECTION FOR ROTATION SINUSOIDAL BEHAVIOUR NON PARTICULAR BEHAVIOUR NON PARTICULAR BEHAVIOUR NON PARTICULAR BEHAVIOUR MANUAL POSITION REPETIBILITY 0,27 0,1 0,5 0,6 PR GLOBAL REPEATIBILITY 0,27 0,1 0,5 0,6 PR GLOBAL REPEATIBILITY 0,27 0,1 0,5 0,6 PR GLOBAL REPEATIBILITY 0,22 0,41 -0,3 PR GLOBAL REPEATIBILITY 0,22 0,41 -0,3 PICK AND PLACE 0,22 0,41 -0,3 SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SMALL CORRECTION	BARI BRUXELLES MANUAL POSITION REPETIBILITY PR INTRINSIC REPEATIBILITY PR GLOBAL REPEATIBILITY PICK AND PLACE CORRECTION FOR ROTATION 0,9 1,1	BARI BRUXELLES MANUAL POSITION REPETIBILITY 0,9 1,1 PR INTRINSIC REPEATIBILITY 0,9 1,1 PR GLOBAL REPEATIBILITY 0,05 0,06 0,016 0,18 0,03 0.07 PICK AND PLACE 1,05 1,04 0,9 1,28 0,007 0,7 -0,3 2,198 CORRECTION FOR ROTATION SINUSOIDAL BEHAVIOUR NON PARTICULAR BEHAVIOU SINUS LYON PERUGIA <x> x Y> y <x> x Y> y <x> MANUAL POSITION REPETIBILITY 0,27 0,1 0,5 0,6 0,04 PR INTRINSIC REPEATIBILITY 0,27 0,1 0,5 0,6 0,05 0,6 PR INTRINSIC REPEATIBILITY 0,22 0,41 -0,3 1,4 SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SINUS PR GLOBAL REPEATIBILITY 0,22 0,41 -0,3 1,4 SINUS PR GLOBAL REPEATIBILITY 0,22 0,41 -0,3 1,4 SINUS SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SINUSOIDAL BEHAVIOUR SINUS SINUS SINUSO</x></x></x>	BARI BRUXELLES MANUAL POSITION REPETIBILITY 0,9 1,1	BARI BRUXELLES FNA MANUAL POSITION REPETIBILITY 0,9 1,1 v

Module Mechanical Precision

- Before/after glue curing, fiducials of sensors, hybrid, and carbon fiber frame are measured
 - → Requirements on relative positions and angles between the sensors, the hybrid and the frame are made
 - → ∆x and relative angle between sensors and between the frame and the sensors are most critical
- All modules (but 1) have passed these requirements
- On some modules, the measurements are repeated on an independent precision measuring machine
 - → All measurement are consistent in these cross checks.







Bonding Centers



- All centers are equipped with good bonding machines (mainly Delvotec and K&S) and are fully operational
 - → Bari,Catania, Firenze, Padova, Pisa, Torino → TIB/TID Modules
 - → Aachen, Hamburg, Karlsruhe, Strasbourg, Wien, Zurich → TEC Modules
 - → FNAL, UCSB → TOB Modules
- Most of the centers have prior experience from other experiments
- Pitch adaptors and other test structures have been distributed between centers for bond quality testing





Bonding Qualification



- Each bonding center has been sent multiple bonding test pieces
- Wire bonds have their pull strengths, shapes, and break location studied at the center and at CERN
- All bonding centers have passed qualification with pull strengths greater than 9 grams

ID#	Centre	CERN bond	Self test§	CERN test	comments
1	Torino	10.7 ± 0.6	12.5 ± 1.5	13.9 ± 0.9	Slight under deformation
2	Bari	11.6 ± 0.4	8.5 ± 1.0	10.7 ± 0.6	good
3	Catania	10.2 ± 0.4	7.1 ± 0.8	7.1 ± 0.4	Slight over deformation
4	Florence	11.1 ± 0.4	8.4 ± 0.9	8.3 ± 0.9	good
5	Karlsruhe	11.4 ± 0.4	10.7 ± 0.5	$\sim 10 \pm 0.5$	Very low loop:400µm
6	Strasbourg	11.6 ± 0.5	10.6 ± 0.5	11.2 ± 0.6	good, low loop:600µm
7	Vienna	10.3 ± 0.5	7.3 ± 1.7	10.0 ± 1.8	Lift-offs, large spread
8	Aachen	9.2 ± 0.4	11.0 ± 1.7	8.4 ± 2.0	Lift-offs, large spread
9	Padova 1	8.7 ± 0.4	10.3 ± 1.5	12.1 ± 1.5	On Hughes, large spread
10	Padova 2	8.7 ± 0.4	8.5 ± 1.2	9.8 ± 1.6	K&S, lift-offs, spread
11	Pisa 1	11.4 ± 0.5	6.5 ND	11.8 ± 0.7	Do destructive test
12	Pisa 2	9.1 ± 0.4	?		Test new K&S
13	Zurich 1	9.9 ± 0.4	$9.9 \pm 1.1?$	8.5 ± 0.8	Very high loop
14	Zurich 2	8.9 ± 0.4	$10.3 \pm ?$	14.6 ± 0.9	Amazing!
15	FNAL 1	9.0 ± 0.4	10.6 ± 1.1	10.4 ± 1.1	Good but some lift-offs
16	UCSB	-	9.6 ± 0.3	9.9 ± 0.4	good
17	FNAL 2	10.3 ± 1.0	10.8 ± 0.9	10.7 ± 1.9	1 bad bond in CERN test some lift-offs
4	§= corrected value based	on CERN measured he	ight and length	in purple = some areas	of improvement to work on
			1		Alan Honma, CERN

Result of 1st bond test

Tracker Annual Review 2003, A. Affolder, UCSB

Bonding QC&A During Production

- Pull strengths, bond deformation, and lift-off measurements are made
- on the test pad of pitch adaptor
 Every 50th wire bond will be

•

- Every 50th wire bond will be destructively pull tested and replaced on first ~20 module of each type at each test center
- Bond heads are regularly inspections and replaced when necessary
- A large number (>100) of hybrids and modules have been thermal cycled between -20 and 20 C with no wire bond breakage seen



Hybrid & Module Electrical Testing



- Hybrids and modules are tested during the various stages of module production
 - Ensure that the performed operations do not introduce any or very few defects
 - Currently require <2% faulty channels per module
 - → CERN, Louvain, Strasbourg, UCSB -> Hybrid Tests
 - → Bari/Catania, Firenze, Padova, Perugia, Pisa, Torino -> TIB/TID Modules
 - → Aachen, Brussels/Antwerper, Karlsruhe, Lyon, Louvain,
 - → Strasbourg, Wien, Zurich -> TEC Modules
 - → FNAL, UCSB -> TOB Modules
- A big effort of standardization in the hardware and software setups has been accomplished.
 - → Only ARCS and DAQ-based testing stand are foreseen to be used
 - → Both systems use the same data analysis and fault finding algorithms
 - Data file and database outputs of the two systems are being standardized



ARCS Based Test Stands





- ARCS <u>APV Readout Controller Software</u> Purpose - Fast testing of hybrids and modules
 - Hybrid testing
 - \rightarrow 28 test stands
 - Module testing \bullet
 - → LED systems
 - Pinhole/Open Tests
 - → DEPP HV supply
 - Automated IV curves
 - → Pre-bonding Test (19 test stands)
 - → Post-bonding Test (15 test stands)



DAQ Based Test Stands



DAQ system - a PC based prototype of the real CMS tracker readout chain Purpose - fast and burn-in testing of modules and sub-structures



Tracker Annual Review 2003, A. Affolder, UCSB







Tracker Annual Review 2003, A. Affolder, UCSB





- Hybrids are tested prior to module assembly and bonding
 - → Ensure no damage has occurred during process
 - → Hybrids have had extensive QC & A prior to module assembly
 - See F. Hartmann's talk
- The hybrid quick tests use the same systems (ARCS), algorithms, and fault finding requirements as the hybrid QC & A



Module Tests



- Module testing has matured greatly recently with the production of >50 modules of a given type.
 - → Minimum set of tests defined
 - → Fault finding algorithms are now tuned to maximize fault finding and fault type identification while minimizing false bad channel flagging
- Noise performance and shielding standardization has allowed for the same fault finding algorithms to work on the TIB, TEC & TOB
 - → Minimize the effects of external noise sources
 - Results can be combined for the same module type measured at different sites in order to further refine testing
- Testing procedures are now almost automated
 - → Work to automate testing→ fault finding → module grading → database entry underway



Noise Measurement

Pulse Height Measurement (Using Calibration Pulse)



Tracker Annual Review 2003, A. Affolder, UCSB





Fault Finding Using ARCS (3)

- Test failures are correlated in order to diagnose fault type
 - \rightarrow Open (1 or 2 sensor)
 - → Short
 - → Pinhole/Saturated Channel
 - → Mid-sensor opens
 - → Noisy Channels
- Faults are found >95% with correct fault type identified ~90% of the time
 - → Less than .1% of good channel flagged as faulty
 - → As more modules are built, fault finding criteria will be re-tuned to improve performance
- Database output of module testing is being finalized
 - → Similar tuning of fault finding underway for DAQ-based systems





Test Stand Cross-calibration



- All ARCS systems have had first iteration of cross-calibrations
- Modules are circulated between testing centers
 - → Multiple examples of common problems are added to each module
 - Shorts (neighbors & next-to-neighbors)
 - Opens (sensor-sensor & PA-sensor)
 - Pinholes
- With new qualification standards, results nearly identical
 - → Final iteration of crosscalibrations are currently underway
 - → DAQ cross-calibration is forthcoming



200

100

300

Channel

400

500



Wien cold box



- Wien cold box cycles modules from -20 C to 20 C while reading out up to 10 modules
 - → DAQ Based System
 - Modules cycled 1-3 days with ~4 cycles \rightarrow per day.
 - TIB will cycle all modules \rightarrow
 - TEC/TOB will cycle all modules until sub- \rightarrow structure burn-in available



Inside Wien Cold Box



Backplane of Wien Cold Box



Database



- Lyon Database
 - → Complete description of all parts and assembly
 - → Traces all movements of the parts between centres & keeps inventories
 - → Includes all test results performed at any centre
 - → Allows extract data for
 - Controlling the production
 - Tracing the anomalies
 - Later calibration or slow control purposes



For example, I-V curve of a TOB module at various stages of production



Conclusions



- Module assembly is underway
 - Assembled modules are very uniform and all meet specifications
 - → Wire bond strengths and shapes have been excellent
 - → Module electrical testing is semi-automatically finding the vast majority of faults with a very small false fault finding rate
- With the uniformity of results, the database allows for the tracking of global module quality
 - Any systematic problems can be quickly identified and addressed at the production centers